





How to change the wheel circumference on the Levo 2019

Note: You are the only responsible for any changes you make or attempt to make to your e-bike.

In this short document I will show how you can change the wheel circumference on the Levo 2019, especially for the 2019 models which run TCU firmware version 2.025 or newer.

Please follow the steps exactly in sequence as listed.

1	Install an App that is able to change the wheel size. You can use BLEvo or the old Mission Control 1.1.2. It is not available on Google Play but you can find it at this address: https://www.apkfollow.com/app/specialized-mission-control/com.specialized.missioncontrol/	
2	Get the previous model battery from Levo or Kenevo. Like the one shown here:	
3	Switch off the bike and disconnect the battery from the engine	
4	Remove the TCU (Turbo Connect Unit) display from the down tube	
5	VERY IMPORTANT! -> DISCONNECT BOTH CONNECTORS CIRCLED IN RED	
6	After the disconnection of the connectors of the TCU, connect the old battery to the motor connector	
7	Turn on the old battery connected to the engine	
8	Change the wheel circumference as you wish with the App	
9	Switch off the old battery connected to the engine and wait 5 seconds.	
10	Disconnect the old battery and reconnect the TCU and connect the new 2019 battery	
11	Start the new Mission Control and check the change in wheel circumference.	